


CABINET PARTS


Illus. No.	Part No.	DESCRIPTION				
1		Literature Parts				
	2300272					
2	4344900	Wiring Diagram Cabinet (Not A				
2		Service Part)				
3	4344739	Lens, Light				
4	4344740	Bulb, Light				
5	4344746	•				
6	4344747					
7	4344761	Grille				
8	4344762					
9	4344763					
10	4344764					
11	4344898					
12	4344769	Frame, Side Left Side				
	4344770					
13	4344771					
14	4344840	Evaporator Fan				
	1011010	Assembly				
15	4344859					
16	4344768					
17	4344767	Switch, Plunger				
18	4344826					
19	4344797					
20	4344819	1 /				
21	4344825					
22	4344823					
23	4044004	Frame, Support				
	4344821 4344820	Right Left				
24	4344824					
2 4 25	4344857					
26	4344827	Screw				
27	4344792					
28	4344793					
29	4344791					
30	4344783					
31	4344878	Screw				
32	4344865	Evaporator Fan Motor				
33	4344877	Harness, Wire				
34	4344832	Screw, Ground				
35	4344778	Grommet, Fan Motor				
36	4344899	Bracket, Motor				
37		Evaporator				
		(Not Serviced)				
38	4344858	Switch, Light				
39	4344917	Transformer Cable				

SHELF PARTS




Illus. No.	Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION	Illus <u>No</u> .		DESCRIPTION
1	4344879	Temperature	8	4344850	Stop, Lower Rack	13		Support, Bumper
		Separator	9	4344851			4344885	Left
2	4344844	Wine Rack, (4)	10	4344882	Trim, Top And		4344886	Right
3	4344845	Wine Rack, (1)	'		Middle Racks	14		Screw
4	4344848	Wine Rack, Lower	1 11		Support		4344914	Left
5		Ladder, Shelf	' '	4344866	1.1		4344915	Right
	4344842	Left Side		4344867		15		Transformer Cable
	4344843	Right Side	12		Trim, Lower Rack	16		PCB Display Board
6	4344794		'-		, _56. 114611	17		Screw-W/Washer
7	4344795	Washer						

DOOR PARTS



Illus No.		DESCRIPTION	Illus. No.	. Part No.	DESCRIPTION	Illus No.		DESCRIPTION
1	4344853	Door Assembly (Includes Gasket)	10 11	4344852	Door Gasket Handle, Door	17	4344906	Screw, Lower Hinge Quantity 1
2	W10162992	Washer-Bottom '		4344810	Stainless Steel			Quantity 3
3	W10163191	Gasket, Push Pad		W10202513		18	4344827	Screw
4		Hinge, Bottom	12		Door Skin,	19	W10163072	Screw
5	4344754	Hinge, Top			Stainless Steel	20	4344801	Screw
6	4344755	Spacer, Top Hinge		W10187193	Black	21	4344808	Screw
7	4344756		13	4344760		22	4344813	Nameplate
		Bottom Hinge	14		Spacer, Door			
8	4344757	Actuator, Switch	15	4344904				
9		Door Stop	16		Screw		OPTION	IAL PARTS
		Stainless Steel			Stainless Models		NOT ILL	USTRATED
	W10163074	Black		W10162988	Black Wrap Models			
							8171420	Cleaner, Stainless Steel (12 oz)

UNIT PARTS



_								
Illus	s. Part		Illus	. Part		Illus	. Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	W10163193	Drain Pan	12	1211702	Ean Blada	28	4344775	Compressor
2	4344773		12		Fan Blade	20	4344773	(Includes Items
2	4344773	Defrost Timer	13		Bracket, Motor			
_	4044774		14		Bracket, Motor	1 00	40.4400.4	5, 8, 16, 17 & 21)
3		Defrost Timer	15		Cover, Rear	29	4344834	
4	4344797		16	4344837	Capacitor	30	4344833	
5		Start Device	17	4344836		31		Transformer
6	W10175971	Mounting Plate,	18	W10163276	Trap, Drain	32	W10163278	Thermostat
		Compressor	19		Power Cord	33	4344864	Bracket,
7	4344778	Grommet, Fan Motor	20	4344829	Cable Tie			Thermostat
8	4344779	Grommet.	21	W10163273	Drier	34	4344881	Ballast
		Compressor	22	4344838	Bushing	35	4344907	Trim, Edge
9	4344780	Bolt, Compressor	23		Clip, Bushing	36		Support, Drain
10	4344781	Fan Motor,	24	W10163274	Pad, Rubber			
		Condenser	25	4344826		REF	FRIGERA	NT CHARGE
11	4344782	Baffle, Air	26	4344825	Screw			
			27	4344832	Screw			3.5 Ounces
			I			I		(R-134A)